



## **ZOMBIE**

These Zombie Instructions is an outdated version. If you purchased your controller after 1/14/2019 or want to get familiar with the latest software update please visit **this page**.

## **Navigate To:**

- What is Zombie Auto Aim Mod?
- How Do I Operate Zombie Auto Aim Mod?
- What Games Is Zombie Auto Aim Mod Compatible With?

## What is Zombie Auto Aim Mod?

Zombie mod allows to auto-aim at the closest zombie's head or chest once you scope your rifle. The mod is compatible with Campaign in the latest Call of Duty entries.

# **How Do I Operate Zombie Auto Aim Mod?**

### To activate:

- Hold down mod switch on the back
- Hold down Right Bumper and then tap Left Trigger (in default button layout) A special WHITE LED will illuminate on an available slot to let you know zombie auto-aim is active. Pull Left Trigger (in default button layout) like normal to aim and move the target near a zombie, the mod will pulse the scope-weapon button and cause the crosshairs to lock onto the nearest enemy.

### To turn OFF:

- Hold down mod switch on the back
- Hold down Right Bumper and then tap Left trigger (in default button layout). A special WHITE LED (2, 3 or 4) will turn OFF indicating that special feature has been turned OFF.

You can turn OFF all special modes (2,3 and 4 LEDs) at any time by holding down mod switch on the back and tapping A button. All 2,3 and 4 LEDs will turn off indicating that all special features have been turned OFF.

# What Games Is Zombie Auto Aim Mod Compatible With?

Zombie Mod is compatible with Campaign and Zombie modes in Call of Duty games. It is NOT compatible in Multiplayer and Zombie Mode in AW.