



AUTO SPOT

These Auto Spot Instructions is an outdated version. If you purchased your controller after 1/14/2019 or want to get familiar with the latest software update please visit **this page**.

Navigate To:

- What is Auto Spot Mod?
- How Do I Operate Auto Spot Mod?
- What Games Is Auto Spot Mod Compatible With?

What is Auto Spot Mod?

In Battlefield 4 you can help out your team by "spotting" an enemy. Once an enemy is spotted, he will show up on your teammate's radar and you may even get extra points when that enemy is vanquished. In Battlefield 4 on the new PS4 console, this is accomplished by manually pressing R1 button (in default button layout). The Auto Spot mod will do it for you whenever you scope your weapon. The Auto Spot mod will spot the enemies when you scope your weapon as this helps prevent the BF4 anti-cheater filter from blocking your mod.

When Auto Spot mod is turned on, you no longer have to manually press these buttons. Enemies will be automatically spotted (as the controller will automatically press the spotting button for you) when you pull L2 button to aim.

How Do I Operate Auto Spot Mod?

To activate:

- Hold down mod switch on the back
- Hold down R1 button and then tap D-pad UP button (in default button layout). A special LED will glow YELLOW to let you know Auto Spot has been activated. Scope your weapon like normal and the controller will spot enemies for you.

To turn OFF:

- Hold down mod switch on the back
- Hold down R1 button and then tap D-pad UP button (in default button layout). A special LED (2, 3 or 4) will turn OFF indicating that special feature has been turned OFF.

You can turn OFF all special mods (2, 3 and 4 LEDs) at any time by holding down mod switch on the back and taping X button. All 2, 3 and 4 LEDs will turn off indicating that all special features have been turned OFF.

What Games Is Auto Spot Mod Compatible With?

Auto Spot Mod is compatible with Battlefield games.