

JITTER

Navigate To:

- What is Jitter Mod?
- How does Jitter work?
- How do the different Jitter modes work?
- What Games Is Jitter Mod Compatible With?
- How do I program in my very own custom Jitter speed?

What is Jitter Mod?

Jitter mod takes advantage of a glitch in some Call of Duty games. This allows weapons to shoot faster than they were originally intended to shoot. Jitter mod was completely patched in BO3, Advanced Warfare, and MW3. Shotgun jitter was patched in BO2. Jitter works in all other Call of Duty games. This is an advanced feature intended for experience mod users.

How does Jitter work?

To enable jitter during play, hold the mod switch and tap the d-pad up. LED 1 will turn YELLOW.

To turn OFF:

- Hold down mod switch on the back.
- Tap D-pad down button. The first LED will turn OFF. Jitter is OFF.

How do the different Jitter modes work?

Start by turning on Jitter. Then, to change to a different jitter mod in the middle of gameplay, hold the mod switch and hold d-pad up. LED 1 will blink yellow. Count the number of blinks on LED 1 and release the buttons when you arrive on the mode you want:

- Mode 1: "7" speed number. Jitter YY glitch.
- Mode 2: "7" speed number. Jitter YY glitch. While scoped, jitter turns off.
- Mode 3: "7" speed number. Jitter XYY glitch.
- Mode 4: "7" speed number. Jitter XYY glitch. While scoped, jitter turns off.
- Mode 5: "255" speed number. Jitter YY glitch.
- Mode 6: "255" speed number. Jitter YY glitch. While scoped, jitter turns off.
- Mode 7: "136" speed number. Jitter XYY glitch.

Mode 8: "136" speed number. Jitter XYY glitch. While scoped, jitter turns off.

You can further customize each mode (see below).

What Games Is Jitter Mod Compatible With?

Jitter Mod is compatible with some Call of Duty games.

How do I program in my very own custom Jitter speed?

You've mastered the use of jitter and you're ready to dial in your own custom jitter speed. Jitter can accept a "speed number" from 0 through 255. The lower the number, the faster the mod will try to glitch shoot.

- First, turn on jitter and scroll to the mode you would like to edit.
- Now, hold the mod switch and then tap the Sync button. All four LED's will light up in WHITE to let you know that it's waiting for further input.
- Tap the d-pad up button. All four LED's will blink in YELLOW to let you know we're going to start programming the rapid fire speed.
- Let's say your speed started at a speed number of 136. The mod will blink the "hundreds" digit on LED 1. The mod will do one flash to indicate a "0" number.
- Now, you can tap the left trigger to decrease the hundreds digit, or tap the right trigger to increase the hundreds digit. The mod will blink to let you know what the current number is. When you're happy with the number, tap the mod switch to move to the next number.
- Now we're at the "tens" digit and the tens digit will blink on LED 2. Follow the
 procedure from above; tap the left trigger to decrease the tens digit, and tap the right
 trigger to increase the tens digit. Tap the mod switch to save that digit and move to
 the ones place.
- Lastly, we're at the ones place. Follow the procedure from above one last time; tap the
 left trigger to decrease the ones digit, and tap the right trigger to increase the ones
 digit. Tap the mod switch to save your selection. The mod will blink all LED's in GREEN
 three more times to let you know that your new speed was saved.